


# 15,000lt TRAFFICABLE - RW15HD Lifting Instructions

Mass Weight = 10.5 Tonne
Tank = 7.1 Tonne
Lid = 3.4 Tonne
Total Height = 2100mm
Total Width = 3450mm


# **LID SIDE VIEW**




LID SUPPLIED NOT SEALED TO TANK FOR SEPARATE LIFTING


- 1. Always use certified lifting equipment
- 2. The Lid has  $3 \times 2.5$  tonne swiftlifts for the separate lifting of the lid if required
- 3. The tank has 4 x 5 tonne swiftlifts on the internal of the tank for lifting  $% \left( 1\right) =\left( 1\right) ^{2}$
- 4. Always ensure the tank is empty before lifting

### **LID TOP VIEW**



**REACH OF CRANE/ CRANE TRUCK**To be determined by your crane/ crane truck operator.






**TANK SIDE VIEW** 

LID TOP VIEW



# 15,000lt TRAFFICABLE - RW15HD Excavation Instructions

Mass Weight = 10.5 Tonne
Tank = 7.1 Tonne
Lid = 3.4 Tonne
Total Height = 2100mm
Total Width = 3450mm




**TANK SIDE VIEW** 

- 1. Dig hole 4000mm square & 2350mm Deep
- 2. Cover base of hole with 100mm of 5mm to 7mm drainage gravel
- 3. Ensure bottom of hole is level
- 4. Backfill with soil/sand. Avoid backfilling with large rocks
- 5. To prevent flotation while not connected to stormwater, the tank must be filled with 70% (10,500lt) of water immediately after installation

## TRUCK ACCESS

Unloading of tank via the back of the truck NOT SIDE. Ensure BACK of truck has clear level 6m wide access to the edge of the hole.

**REACH OF CRANE/ CRANE TRUCK**To be determined by your crane/ crane truck operator.



**LID TOP VIEW**