



5,000lt TRAFFICABLE - RW5HD

Lifting Instructions


Mass Weight = 5 Tonne

Tank = 3.4 Tonne

Lid = 1.6 Tonne

Total Height = 1900mm

Total Width = 2400mm




1. Always use certified lifting equipment
2. The tank has 3 x 2.5 tonne swiftlifts on the inside of the tank for lifting
3. Always ensure the tank is empty before lifting.

TRUCK ACCESS

Unloading of tank via the back of the truck
NOT SIDE. Ensure BACK of truck has clear
level 6m wide access to the edge of the hole.

REACH OF CRANE / CRANE TRUCK

To be determined by your crane / crane truck
operator.






5,000lt TRAFFICABLE - RW5HD

Excavation Instructions

Mass Weight = 5 Tonne
Tank = 3.4 Tonne
Lid = 1.6 Tonne
Total Height = 1900mm
Total Width = 2400mm



1. Dig hole 2950mm square & 2000mm deep
2. Cover base of hole with 100mm of 5mm to 7mm drainage gravel
3. Ensure bottom of hole is level
4. Backfill with soil / sand. Avoid backfilling with large rocks
5. To prevent flotation while not connected to stormwater, the tank must be filled with 70% (3,500lt) of water immediately after installation

TRUCK ACCESS

Unloading of tank via the back of the truck NOT SIDE. Ensure BACK of truck has clear level 6m wide access to the edge of the hole.

REACH OF CRANE / CRANE TRUCK

To be determined by your crane / crane truck operator.

